

## 4.7.1 CPU card interface connectors






Figure 9: CPU card interface connectors

## Key to Figure 9: CPU card interface connectors

Feature	Description
<p style="text-align: center;"><b>A</b></p>	<p><b>GPI/RLY Interface Connector</b></p> <p>The RJ-45 socket labeled <b>GPI/RLY Interface</b> connects the CPU card to a GPI-6 or RLY-6 card. The GPI-6 provides six general-purpose opto-isolated logic inputs. The RLY-6 card provides six single-pole, double-throw relay outputs.</p> <p>Both card types mount in either an IMF-3 interface frame or an IMF-102 interface frame. Up to ten GPI-6 or RLY-6 cards can be operated at one time from the matrix by daisy-chaining the cards together. Each card has an IN and an OUT connector for this purpose.</p> <p>The RLY-6 and GPI-6 cards connect to the GPI/RLY interface connector using shielded category-5 cable. For more information about the GPI-6 and RLY-6 cards, consult their respective manuals in the Eclipse HX documentation set.</p> <p>Note:  <i>If this port is used a ferrite core must be added to the socket end of each cable. A suitable ferrite core is <b>Würth Elektronik part: 74271132</b>.</i></p> <p><i>A shielded cable should be used.</i></p> <p>For wiring pinout information for GPI/RLY interfaces, see:</p> <ul style="list-style-type: none"> <li>• The <b>Relay Interface Module (RLY-6) Instruction Manual</b>.</li> <li>•</li> <li>• The <b>General Purpose Inputs (GPI-6) Instruction Manual</b>.</li> </ul>
<p style="text-align: center;"><b>B</b></p>	<p><b>RS-232 DB-9 Connector</b></p> <p>The DB-9 connector labeled RS-232 connects the Eclipse HX-Omega matrix to an external computer. To connect a computer to the matrix, run cable from the RS-232 connector to the PC's serial port. The maximum recommended length of the cable is approximately 10 feet (3 meters). A computer has either a 9-pin serial port or a 25-pin serial port.</p>



**Figure 10: Wiring the matrix DB-9M to the PC DB-9F**



**Figure 11: PC DB-25F connector to matrix DB-9M**

	<p><b>Alarm I/O Connector</b></p> <p>The DB-9F connector labeled <b>Alarm I/O</b> connects the matrix to a control circuit for an external alarm, such as a light or bell. The external alarm activates whenever an alarm condition is detected in the matrix.</p> <p>The following conditions trigger an alarm:</p> <ul style="list-style-type: none"><li>• If any of the voltages produced by the first power supply unit fall below their normal levels.</li><li>• If any of the voltages produced by the second power supply unit fall below their normal levels.</li><li>• If an external alarm circuit or other logic circuit connected to the power supply is activated.</li><li>• If either of the two power-supply unit fans stop operating.</li><li>• If software on a master CPU card generates an alarm.</li></ul> <p>An alarm condition activates the relay contacts connected to <b>pins 4, 5, and 9</b>. These contacts are “dry”, (no voltage is supplied to them by the matrix) and are rated at <b>1 A at 24 VDC</b>. They should not be used for AC mains line current.</p> <p>Pins are provided for adding an additional alarm source to the matrix’s alarm system. <b>Pin 6</b> is an alarm input to the Eclipse HX-Omega matrix. It is connected to the input of a 3.3 V logic device. A logic high on this input will cause the Eclipse HX-Omega matrix to detect an alarm condition. A logic low or an open circuit will cause the Eclipse HX-Omega matrix to detect no alarm condition.</p> <p><b>Pin 1</b> is a voltage source out of the Eclipse HX-Omega matrix. It is connected through a 10Kohm pull-up resistor to the <b>+5 V</b> supply rail inside the Eclipse HX-Omega matrix.</p> <p>A contact closure placed across <b>pins 1 and 6</b> will also cause an alarm condition.</p> <p><b>Tip:</b> <i>The alarm outputs of the PSU-101 power supply could be wired directly to these pins allowing the CPU card to report PSU failures also.</i></p>




Figure 12: Wiring the Alarm I/O DB-9F to the Alarm Relay connector




Figure 13: Double-pole double-throw alarm relay

D

### General-Purpose Outputs Connector (GP OUT)

A GPO can be programmed to mute a speaker, to turn on an applause light, to turn on a door lock, or to perform a variety of other functions. For example, to get the attention of a panel operator working in a high-noise environment such as a control booth, a relay can be programmed to switch on a light at the operator panel each time an incoming call is received, to ensure that the call is not missed.

Note:

If the **GP-OUT** port is used on an Eclipse HX-Omega matrix fitted with XP power supplies (part 740101Z) the following filter must be fitted between the PROC-RCC socket and the cable:

**CINCH FA-25PS/1-LF 25W D-type in-line 1000pF filter**

**(UK supplier: Farnell 111-4108)**

If the matrix is equipped with Power-One power supplies (part 720379Z) this filter **must not be fitted**. If this filter is already fitted to matrix and the power supplies are changed to Power-One units the filter must be removed before

the matrix is powered up.

The DB-25 connector labeled **GP OUT** connects the matrix to eight double-pole double-throw (DPDT) relays with contact ratings of 30 VDC at 1A.

Each general-purpose output has a relay inside the matrix. When a general-purpose output is inactive, the associated **common** pin on the **GP OUT** connector will be shorted to the relevant **normally closed** pin. When a general-purpose output becomes active, the short between the **common** pin is broken and a new connection is made between the **common** pin and the **normally open** pin.

DB-25 Male Connector

PIN	DESCRIPTION
1	RELAY 1 Common
2	RELAY 1 Normally Closed
3	RELAY 1 Normally Open
4	RELAY 2 Common
5	RELAY 2 Normally Closed
6	RELAY 2 Normally Open
7	RELAY 3 Common
8	RELAY 3 Normally Closed
9	RELAY 3 Normally Open
10	RELAY 4 Common
11	RELAY 4 Normally Closed
12	RELAY 4 Normally Open
13	GROUND
14	RELAY 5 Common
15	RELAY 5 Normally Closed
16	RELAY 5 Normally Open
17	RELAY 6 Common
18	RELAY 6 Normally Closed
19	RELAY 6 Normally Open
20	RELAY 7 Common
21	RELAY 7 Normally Closed
22	RELAY 7 Normally Open
23	RELAY 8 Common
24	RELAY 8 Normally Closed
25	RELAY 8 Normally Open




Figure 14: Pin configuration of the GPO connector

**E**

**General-Purpose Inputs Connector (GP IN)**

The DB-25 connector labeled **GP IN** connects the matrix to eight local general-purpose inputs (GPIs).

An external device such as a foot switch, a panel-mounted switch or the logic output of some other device can be connected to the **GP IN** connector. When the external device is activated, it sends a control signal into the matrix to perform one of several preset functions, such as turning a user panel's microphone on or off, muting a microphone's output, or turning a panel's speaker off. The function to perform and the panel upon which it is performed is configured using EHX.

A shielded cable should be used.

The general-purpose inputs operate in one of two modes: the **opto-isolated** mode or the non-isolated mode.

The opto-isolated mode requires the externally connected equipment to provide the current to power the general-purpose input. The non-isolated mode does not require that the externally connected equipment powers the general-purpose input. The current is supplied by a voltage output on the **GP IN** connector.

To select a mode, move the J1 jumper on the CPU rear card to one of two positions. The J1 jumper is located on the inner-matrix side of the DB-25 connector.

For **opto-isolated mode**, fit the J1 jumper across **pins 1 and 2**.

For **non-isolated mode**, fit the J1 jumper across **pins 2 and 3**.

It is recommended that the connector is set to the fully opto-isolated mode.

### Opto-isolated mode




Figure 15: Opto-isolated mode

In this mode, a DC voltage of between 7 and 24 volts is required at the EXTVIN+ pin with relation to the EXTVIN– pin. To cause an input to detect an active signal, current must flow from the relevant input pin.

The external device should draw no current to cause an inactive input and at least 5 mA to cause an active input. The opto-isolator drive line contains a 1.5 kOhm resistor to limit the current through the opto-isolator. Therefore the input pins can be connected directly to the EXTVIN– level to cause an active input.

The voltage level at the external input pin should not be allowed to go below EXTVIN– or above +6 V with respect to EXTVIN–.

### Non-isolated mode

To cause an input to detect an active signal in non-isolated mode, the current must flow from the relevant input pin.

The external device should draw no current to cause an inactive input and at least 5 mA to cause an active input. The opto-isolator drive line contains a 1.5 kOhm resistor to limit the current through the opto-isolator.

Therefore the input pins can be connected directly to a ground pin to cause an active input.

The voltage level at the external input pin should not be allowed to go below ground or above +6 V with respect to ground.




Figure 16: Non-isolated mode

DB-25 Female Connector

PIN	DESCRIPTION
1	Logic Input 1
2	Logic Input 2
3	Logic Input 3
4	Logic Input 4
5	N/A
6	N/A
7	N/A
8	N/A
9	Ground
10	Ground
11	Ground
12	Ground
13	Ground
14	Logic Input 5
15	Logic Input 6
16	Logic Input 7
17	Logic Input 8
18	N/A
19	N/A
20	N/A
21	N/A
22	Voltage In+
23	Voltage In+
24	Voltage In-
25	Voltage In-




Figure 17: Pin configuration of the General Inputs connector

**F**

**Local Area Network connector (LAN1)**

The **LAN1** and **LAN2** connectors have standard Ethernet pin assignments. See **G** below for pin assignments.

The RJ-45 socket labeled **LAN 1** connects a local area network (LAN) to the CPU card through a standard Ethernet connection. The **green** LED indicates the port is connected and the amber LED indicates activity.

	<p>Note:</p> <p><i>If this port is used a ferrite core must be added to the socket end of each cable. A suitable ferrite core is <b>Würth Elektronik part: 74271132</b>.</i></p> <p><i>A shielded CAT-5 cable should be used.</i></p>																		
<p style="text-align: center;"><b>G</b></p>	<p><b>Local Area Network connector (LAN2)</b></p> <p>The LAN1 and LAN2 connectors have standard Ethernet pin assignments.</p> <p style="text-align: center;">LAN1 and LAN2 Ethernet RJ-45 Connectors</p>  <table border="1" data-bbox="721 869 1107 1289"> <thead> <tr> <th>PIN</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Transmit data +</td> </tr> <tr> <td>2</td> <td>Transmit data –</td> </tr> <tr> <td>3</td> <td>Receive data +</td> </tr> <tr> <td>4</td> <td>Unused</td> </tr> <tr> <td>5</td> <td>Unused</td> </tr> <tr> <td>6</td> <td>Receive data –</td> </tr> <tr> <td>7</td> <td>Unused</td> </tr> <tr> <td>8</td> <td>Unused</td> </tr> </tbody> </table> <p style="text-align: center;"><b>Figure 18: LAN1 and LAN2 pin assignments</b></p> <p>The <b>green</b> LED indicates the port is connected and the <b>amber</b> LED indicates activity.</p> <p>Note:</p> <p><i>If this port is used a ferrite core must be added to the socket end of each cable. A suitable ferrite core is <b>Würth Elektronik part: 74271132</b>.</i></p> <p><i>A shielded CAT5 cable should be used.</i></p>	PIN	FUNCTION	1	Transmit data +	2	Transmit data –	3	Receive data +	4	Unused	5	Unused	6	Receive data –	7	Unused	8	Unused
PIN	FUNCTION																		
1	Transmit data +																		
2	Transmit data –																		
3	Receive data +																		
4	Unused																		
5	Unused																		
6	Receive data –																		
7	Unused																		
8	Unused																		

**Table 5: Key to CPU card interface connectors**

## 4.8 DSE1/T1 Matrix to Matrix crossover cable connections

For E1 and T1 direct matrix to matrix connections the CAT5 crossover cables should be wired.

Matrix 1 Pin	Description	Matrix 2 Pin
1	To	4
2	To	5
3	Not connected	3
4	To	1
5	To	2
6	Not connected	6
7	Not connected	7
8	Not connected	8

Table 6: E1/T1 Crossover cable

## 4.9 E1/T1 Matrix to Matrix straight cable connections

E1/T1 straight cables may be used to connect E1 or T1 ports to E1 or T1 networks or third party equipment.

Matrix 1 Pin	Description	Matrix 2 Pin
1	To	1
2	To	2
3	Not connected	3
4	To	4
5	To	5
6	Not connected	6
7	Not connected	7
8	Not connected	8

Table 7: E1/T1 Straight cable

## 4.10 E1 to FreeSpeak® / CellCom® / FreeSpeak II™ antenna straight cable connection

Straight CAT-5 cables are used to connect an E-QUE card to a FreeSpeak / CellCom / FreeSpeak II antenna or splitter.

The E1 pinout for connecting an antenna or splitter is shown in **Table 8: E1 pinout for connecting a FreeSpeak / CellCom / FreeSpeak II antenna or splitter.**

Cable wiring is shown in **Table 9: E1 to FreeSpeak / CellCom / FreeSpeak II antenna or splitter straight cable connection.**

Pin	Description
1	Tx+
2	Tx-
3*	DECTSYNC+
4	Rx+
5	Rx-
6*	DECTSYNC-
7*	GND
8*	12V

**Table 8: E1 pinout for connecting a FreeSpeak / CellCom / FreeSpeak II antenna or splitter**

Matrix 1 Pin	Description	Matrix 2 Pin
1	To	1
2	To	2
3	Not connected	3
4	To	4
5	To	5
6	Not connected	6
7	Not connected	7
8	Not connected	8

**Table 9: E1 to FreeSpeak / CellCom / FreeSpeak II antenna or splitter straight cable connection**