BAT60 Evaluation Steps

Step	Action	Description
1	Initial detection of failure mode when BAT60 is not charging:	Clear Com [®] (HRCCD) 281 052 (227)327 (D) (D) (D) (D) (D) (D) (D) (D) (D) (D)
	 a) The "A" button will show Green. b) The display will show "CHARGED" c) The battery will show a less than 100% charge. 	the fail of the fa
	Normal function for both the battery and the ck when the battery is charging correctly:	 ✓ "A" button will be Red. ✓ Display will read "CHARGING"
Clear-Com D3% D2654 227320 COM D2654 22754 22754 COM D2654 22754 22754 COM D2654 22754 22754 COM D2654 22754 22754 COM D2654 22754 22754 COM D2654 22754 22754 COM D2654 22754 COM D26554 COM D26554 COM D265554 COM		

BAT60 Evaluation Steps

Step	Action	Description
2	Knowing the charge of the BAT60 is less than full charge; to confirm battery malfunction remove the battery from the Beltpack, and place it directly on the AC60 Charger. If the indicator immediately turns Green, this confirms a battery failure.	THE RATEO
3	If the charger indicator turns Red, the battery is functioning correctly and further evaluation of the Beltpack should be peformed.	