


Vertex Standard VX 231/ VX350 series



Set Jumpers to the following positions: J6 off; J7 on; J8 on.

Set Jumpers to the following positions: J6 off; **J7 off**; J8 on if higher output is desired.