

CC-300 & CC-400 Service Part List

| | Photo | Part Number | Part Description | CC-300 Use | CC-400 Use Q'TY | Note |
|----|---|----------------|-------------------------------------|------------|-----------------|--|
| 1 |  | 506100Z | Ear Baffle Assembly | 1 | 2 | Replacement ear element includes the baffle with driver. |
| 2 |  | 506101Z | Unit Assembly | 1 | 1 | Replacement microphone element includes the holder with capsule. |
| 3 |  | 506102Z | Microphone Assembly | 1 | 1 | Replacement rubber boot and microphone housing assembly: Include the badge on the mic boom. No capsule on this assembly. |
| 4 |  | 506103Z | Head Band Assembly (CC-300) | 1 | ---- | Replacement headband assembly for CC300 |
| 5 |  | 506104Z | Head Band Assembly (CC-400) | ---- | 1 | Replacement headband assembly for CC400: Include inner cord. |
| 6 |  | 506105Z | Ear Housing Assembly (Right) | ---- | 1 | Replacement ear cup assembly right: With badge and inner cord on it. |
| 7 |  | 506106Z | Ear Housing Assembly (Left, CC-300) | 1 | ---- | Replacement ear cup assembly left (mic side) - without inner cord |
| 8 |  | 506111Z | Ear Housing Assembly (Left, CC-400) | ---- | 1 | Replacement ear cup assembly left (mic side)- with inner cord |
| 9 |  | 506107Z | Temple Pad Assembly (CC-300) | 1 | ---- | Replacement CC-300 temple pad assembly |
| 10 |  | 506108Z | Ear Pad | 1 | 2 | Replacement ear cup pad |
| 11 |  | 506109Z | Pop Filter | 1 | 1 | Replacement microphone pop filter |
| 12 |  | 506110Z | Pad | 1 | ---- | Replacement CC-300 temple pad cushion |
| 13 |  | HS-BAG | Pouch | 1 | 1 | Replacement headset pouch |
| 14 |  | HS-ES | Ear Cover | 1 | 2 | Replacement ear sock |

| | | | | | | |
|----|---|----------------|-----------------------|---|---|---------------------------------|
| 15 |  | 506119Z | Plastic Cover (Left) | 1 | 1 | Replacement joint cover (left) |
| 16 |  | 506120Z | Plastic Cover (Right) | 0 | 1 | Replacement joint cover (right) |
| 17 |  | HS-WS | Wind Screen | 1 | 1 | Windscreen and wire tie |

| CC-300 & CC-400 Cable List | | | |
|----------------------------|--------------|---|------|
| | Part Number | Part Description | Note |
| 18 | HC-X4 | CC-300/400 Replacement Cable Assembly with Four-pin Female XLR for Standard Clear-Com Connection. | |
| 19 | HC-Y4 | CC-300/400 Replacement Cable Assembly with Four-pin male XLR for Standard RTS Connection. | |
| 20 | HC-X5 | CC-300/400 Replacement Cable Assembly with Five-pin Male XLR Connector | |
| 21 | HC-X6 | CC-300/400 Replacement Cable Assembly with six-pin male XLR connector | |
| 22 | HC-X7 | CC-300/400 Replacement Cable Assembly with seven-pin female XLR connector | |
| 23 | HC-Y5 | CC-300/400 Replacement Cable Assembly with Five-pin Female XLR Connector (made in house from HC-B6) | |
| 24 | HC-B6 | CC-300/400 Replacement Cable Assembly with No Connector | |