

Party-Line Product Range

Encore Model #	Description	Replaces PL Pro model #
MS-702	2 Channel headset/speaker main station	MS-232
MS-704	4 Channel headset/speaker main station	MS-440
SB-704	4 channel switchboard main station	SB-440
CS-702	2 channel portable headset main station	CS-222
RM-702	2 Channel headset/speaker remote station	RM-220
RM-704	4 Channel headset/speaker remote station	RM-440
HB-702	2 channel flush mount headset station	MR-202
HB-704	4 channel flush mount headset station	MR-204
KB-702	2 channel flush mount headset/speaker station	KB-211
KB-702GM	2 channel flush mount headset/speaker station with microphone jack and VOX	KB-211GM
KB-701	1channel flush mount push-to-talk speaker station	KB-212
EB7-4W	4-wire adapter board for KB and HB stations	EB-4W
EB7-TW	Two-wire (TW) adapter board for KB and HB stations	EB-TW
PS-702	2 channel rack mount power supply	PS-232
PS-704	4 channel rack mount power supply	PS-464
PK-7	1 channel 0.4amp portable power supply	PK-5
AC-701	Telephone/2-wire interface 1RU	AC-10H
EF-701M	4-wire interface with call signal	EF-1M
IF4W4	Four channel 4-wire interface	IF4-B-4
TW-12C	Systems interface	TW-12B
TW-47	Radio communications interface	TW-40
PIC-4704	IFB central controller	PIC-4000
MA-704	IFB control panel with mic	MA-4 & MA-4N
AX-704	IFB expansion control panel	AX-4
CEP-RK	IFB control & expansion panel rack mount kit	820022
AMS-1027	2 channel stereo amp monitor speaker 1RU	AMS-1025
AB-700	Announcers Console	AB-100
RCS-2700	8x24 channel programmable station assignment panel	RCS-2000
RCU-67	Remote control for RCS-2700	RCU-60
TWC-701	Two-Wire Adaptor	TWC-10A
TWC-704	Four Module Two-Wire Adaptor	TWC-104
FL-7	Call Signal Flasher	FL-1

	EB-4W	EB-TW	EB7-4W	EB7-TW
Encore				
KB-701			X	X
KB-702			X	X
KB-702GM			X	X
HB-702			X	X
HB-704			X	X
PL Pro				
KB-212	X	X		
KB-211	X	X		
KB-211GM	X	X		
MR-202	X	X		
MR-204	X	X		