

CellCom/FreeSpeak Firmware Update Procedures

“Freespeak Upgrader” for Beltpack Updates

- 1) Run “FreeSpeak Upgrader” on the PC (make sure that the correct COM port is selected).
- 2) Make sure the selected Firmware File is the latest Beltpack release (e.g. xxxxx.mot) and is of the correct type.
See the release notes if you have questions.
- 3) Switch on the Beltpack.
- 4) Connect the Beltpack to the PC via the registration cable
- 5) Click Download.
- 6) This will start the beltpack to begin the firmware download. The “FreeSpeak Upgrader” progress bar will start progressing.
- 7) The “FreeSpeak Upgrader” status bar will indicate when the download has completed or failed. If the download failed, remove and reinsert the batteries, check the cables and try downloading again skip to step 5.
- 8) Once the firmware file has downloaded successfully (takes about 2.5 mins)
- 9) Remove the registration cable and power off the Beltpack.
- 10) If the unit is dissembled (**remove at least one battery**) fit the unit back together and replace the screws.
- 11) Replace the batteries and power up the unit and check for the correct version and operation.