1) Hold "CTL" key on your keyboard then select the key label from talk or listen list
2) Place the "orange " key label on to the panel
3) Then double click on the key and in the bottom right hand corner of the screen .. select key specific actions and select dual talk listen

Step 2
Place the "orange " key-label on to the panel

Step 1
Hold "CTL" key on your keyboard then select the key-label from the talk or listen list

Step 3
Then double click on the key and in the bottom right hand corner of the screen .. select key specific actions and select dual talk listen

All	Fixed Groups	Interfaces	Panels	Special Keys

Talk	Listen	Description	
1	1		3
1016	1016		1
DIAL DIAL	DIAL DIAL	DIAL PAD ACTIVATE	
epl	epl		6
ext1	ext1		7
GP001	GP001	New fixed group	1
src	src		8
SUPR SUPR	SUPR SUPR	SUPERVISOR	
v24pd	v24pd		2

All Configurations | e32

1016 - Create Stacked Key | Key-Specific Functions

Rotary Encoder

--- Rotary encoder listen:

Add Selected Label | Remove Listen

Options
Dual Talk & Listen | Activation
☑ Allow Local Programming
- | Interlock Group
Crosspoint | Level Adjustment Applies To